

FEATURES

LAZER SPRAY PAINT is a general-purpose spray paint for both indoor and outdoor use. Formulated with high-quality acrylic resin and concentrated pigments, it delivers vibrant color, high gloss, excellent durability, fast drying, and easy application. It can be used on metal, wood, plastic, furniture, and various items such as tables, chairs, fans, bicycles, steel cabinets, handicrafts, and more. Ideal for general decoration or repair work.

- · Provides a beautiful, smooth finish
- Fast-drying and easy to use
- Suitable for spraying on metal, plastic, and wood surfaces

	PRODU	CT INF	ORMA	TION
--	--------------	--------	------	------

Paint type	Acrylic Resin
Product type	Exterior and Interior
Film appearance	Gloss and Matt
Colour	Various colors (see in colorcards)
Recommended substrate	Suitable for use on motorcycle, bicycle and other multipurpose applications.
Pack size	400 cc

TECHNICAL INFORMATION

Theoretical coverage	2 - 3	m ² per can
No. of coat	> 2	coats
Dry film thickness	30 - 40	microns
Touch dry (25 - 30°C)	5 - 10	minutes
Recoat dry (25 - 30°C)	15 - 20	minutes
Hard dry (25 - 30°C)	40 - 50	minutes

REFERENCE STANDARD

_

APPLICATION

Application Method	-
Diluted by	-
Dilution (%)	-

SURFACE PREPARATION

Metal	Remove old paint, rust, and any contaminants completely. Wipe the surface clean with thinner until
	free from dust, dirt, grease, or any foreign matter. Ensure the surface is thoroughly dry.
Wood	For wooden surfaces, ensure the surface is clean and free from dust, wood splinters, grease, and any
	flaking or peeling paint. For a smoother finish, lightly sand the surface and wipe it again with a clean
	cloth before applying wood primer.
Other Surfaces	Clean the surface thoroughly to remove dust, grease, or any contaminants. Ensure the surface is
	completely dry. For glossy or smooth surfaces, lightly sand with fine-grit sandpaper to enhance paint
	adhesion.

PAINT SYSTEM

Metal Primer Spray Nippon Paint Lazer using the designated primer shade as specified in the catalog (1 coat).





Wood Primer	Apply Nippon Paint Bodelac Undercoat White to prevent mold and fill wood grains,	
	or spray Nippon Paint Lazer using the designated primer shade as specified in the catalog (1 coat).	
Topcoat	Spray Nippon Paint Lazer for 2 coats, or until the surface is fully covered.	
DIRECTIONS FOR USE		
	1. Ensure the surface is clean and free from rust, dust, grease, and any other contaminants.	
	2. Shake the can vigorously before use until the mixing ball rattles. Shake occasionally during use to maintain even mixing.	
	3. Apply a suitable primer as recommended in the product catalogue to achieve the desired finish and	
	color.	
	4. Spray in thin, even coats. Allow each coat to dry for at least 10 minutes before applying the next.	
	Avoid applying a thick coat in one go, as it may cause sagging or improper drying.	
	5. Hold the can approximately 30 cm from the surface while spraying for optimal coverage.6. After use, turn the can upside down and spray briefly to clear the nozzle and prevent clogging.	
HANDING AND STORAG		
HANDLING AND STORAG		
Storage condition	This is a pressurized container. Do not puncture, pierce, or incinerate, even when empty. Store in a	
	dry, well-ventilated area with the lid tightly closed. Avoid direct sunlight and do not expose to	
	temperatures exceeding 40°C. During storage or transport, keep containers properly spaced and	
	segregated from other materials. Flammable substances such as oil-based paints and thinners must	
	be stored separately from other product types to ensure safety.	
Precipitation	Leaving paint cans unused for extended periods can cause the pigment to settle and deteriorate over	
	time. If the can is not shaken thoroughly before use, it may lead to issues such as uneven color, poor	
	coverage, or inconsistent finish during application.	
Shelf life	3 years at 30 - 35 ℃	
SAFETY PRECAUTIONS	Keep away from open flames, heat sources, and sparks. This product is highly flammable and may cause fire or explosion upon exposure. Inhalation of vapors or spray mist may cause respiratory	
	irritation, dizziness, or drowsiness. Direct contact with skin may lead to irritation, while eye contact	
	can cause severe irritation and may impair vision. This product is suspected of affecting the	
	reproductive system or fetal development. Prolonged or repeated exposure, even at low levels, may	
	cause damage to internal organs. This aerosol product is also harmful to aquatic life. Do not release	
	into the environment. Always store, handle, and dispose of this product in accordance with applicable	
	local regulations to ensure the safety of users and the surrounding environment.	
DISCLAIMER	Precautions are indicated on the product container. Use only in a well-ventilated area. Avoid contact	
DISCERIIIER	with skin and inhalation of vapors. If the product comes into contact with skin, wash immediately with	
	soap and water, and remove contaminated clothing. If the product gets into the eyes, rinse thoroughly	
	with water and seek medical attention. Additional safety information is available in the Material Safety	
	Data Sheet (MSDS).	
NOTE	The data are average values for reference only. However, the actual value depends on environmental conditions.	

ww.nipponpaintdecor.com